

Bimonthly Maintenance

This maintenance will help keep the **Advantage Glass Filter** from turning into a biological filter and reducing the flow.

- 1) Follow steps 1-3 of the backwashing instructions. After step 3, turn off blower
- 2) Open lid on top of filter and pour in 2 Tbls. Of Potassium Permanganate and re-close lid
- 3) Perform steps 4 & 5 of the backwashing instructions
- 4) Turn **Glass Filter** valve to "RECIRCULATE"
- 5) Turn **Bead Filter** valve to "FILTER" and turn on pump
- 6) After 12 hours, perform the entire backwashing cycle as normally done

WARNING: The backwash procedure requires the use of Potassium Permanganate. FOLLOW THE INSTRUCTIONS EXACTLY FOR YOUR SAFETY!

WARNING: Should you decide to add the Potassium Permanganate through the top valve and not remove it as per the instructions, YOU MUST ALSO POUR ENOUGH WATER THROUGH THE VALVE TO THOROUGHLY CLEAN ALL OF THE POTASSIUM PERMAGANATE FROM THE INSIDE OF THE VALVE AND THE SCREEN LOCATED IN THE VALVE.

WARNING: If you do not follow the instructions exactly, it can result in blasting Potassium Permanganate into the air and possibly causing blindness. It is recommended to turn your head away from the Glass Filter when turning on the blower unit during backwashing of the Advantage Glass filter.